

## REPLACING BEARINGS ON QRM+ ROAD WHEELS STARTING WITH THE 2013 RANGE

### Tools needed:

- 1 multifunction wrench 325 423 01
- 5 mm Allen wrench
- 17 mm open-end wrench
- Bearing press kits for installing and removing bearings 351 266 01 and M40120

The bearings are accessible after having first removed the free wheel according to the adapted procedure.



Remove the bearings



Fit the new CRL bearing with 351 266 01



Fit the new ORL bearing with M40120