

## REPLACING CX01 BLADES ON COSMIC CXR WHEELS

### Tools needed:


- None



Repeat the operation for the 2nd blade, then inflate to the desired pressure (6 to 11 bar).

### USAGE PRECAUTIONS

- Check the position of your brake pads before each ride. They must never come in contact with the blade:



- Ensure that there is enough clearance between the chain stays and seat stays to avoid all contact between the rim and the frame (very wide rim).
- CXR blades are exclusively compatible with Mavic CXR clinchers/tubulars. The use of any other clinchers/tubulars poses a danger to the rider.
- The CXR wheel/clincher/blade system is exclusively compatible with Mavic CXR brake pads. The use of all other brake pads poses a danger to the rider.
- When the wheel is mounted onto the bike, systematically check that the blade is always in contact around the entire perimeter of the tyre as it may have moved due to contact with the brake pads.
- Remove both blades before deflating and removing your clincher.
- Replace both blades in the event of a puncture, running on a flat or violent impact on the tyre.
- Do not expose your blades to extreme temperatures. Avoid extended exposure to sunlight. When not using your bike, protect your blades by storing them away from inclement weather, light and humidity. Ensure that the tyre is always inflated (2 bar minimum), even when not in use. Do not stretch, cut or bend the blades.
- Do not use a high pressure sprayer as doing so may dislodge and damage the blade. Never wash blades (or clinchers) with solvents such as acetone, gasoline, thinner or bleach. When using soapy water, remove the blades, wait until the wheel is dry, then refit the blades.
- Keep out of reach of children.