

REPLACING THE REAR BEARINGS ON THE R-SYS AND COSMIC CARBONE ULTIMATE WHEELS

Tools needed

- 1 bearing press kit M40120

Remove the axle (see page 23) and free wheel mechanism in accordance with the appropriate procedures for these wheels (refer to www.tech-mavic.com or previous years' technical manuals for the procedures);



Extract the bearings using bearing press kit M40120.



Fit the new bearings using bearing press kit M40120.

Remove the axle (see page 23) and free wheel mechanism in accordance with the appropriate procedures for these wheels (refer to www.tech-mavic.com or previous years' technical manuals for the procedures);